

OUTERIMPACT

BROWNING BUCKMARK - M.R.A (Modular RedDot Adapter) Mounting Instructions

Utilize a certified Gun Smith to install adapter. It is possible to install adapter if a Gun Smith is not accessible, but it is recommended that adapter be installed by a Gun Smith.

WARNING: Never remove or install components on a gun before ensuring the gun is not loaded and the chamber is clear.

Step 1: Locate bag marked "MNT HDWR" and remove the two 8-36 screws.



Step 2: Remove top plate sight from Buckmark. Leave all other exposed components in place.

STEP 3: Align hole on the Ourterimpact mount with the holes in the receiver of the Buckmark.

STEP 4: Place the shorter of the two 8-36 mouning screws in the front hole (barrel end)

STEP 5: Place the longer of the two 8-36 mouning screws in the rear hole.

STEP 6: Torque screws to 25 in/lbs

MOUNTING PATTERNS:	SIGHT Manufacture	SIGHTS Model	SCREWS USED
	VORTEX	VIPER	M3 x 8mm
	BURRIS	FAST FIRE 3	
	BURRIS DOCTOR	FAST FIRE 2	M3 x 6mm
	INSIGHT	MRDS	M3 X 6mm
	EOTECH	MRDS	
	VORTEX	VENOM	M3 X 6mm
	TRIJICON	RMR	#6 SCREWS
	LEUPOLD	Delta Point Delta Point Pro	SIGHT SUPPLIED SCREWS WORK
	VORTEX	RAZOR	M4 SCREWS
SIG SAUER	ROMEO3		
CMORE	RTS & STS		

UTILIZE LIQUID THREAD LOCKER UPON FINAL INSTALLATION OF ALL THREADED FASTENERS.