

# OUTERIMPACT

## S&W M&P Shield Plus Optics Ready M.R.D.A. (Micro Red Dot Adapter) Mounting Instructions

- While it is possible to install this mount without the use of a Gun Smith, we recommend using a certified Gun Smith for Installation

**WARNING:** Never remove or install components on a gun without ensuring the gun is not loaded and the chamber is clear.

**Step 1:** Remove existing optics cover plate from the slide.

**Step 2:** Test fit the Red Dot sight to Outerimpact adapter, utilizing adjacent chart. Note: Make sure screws do not stick out beyond bottom of adapter. After test fitting, remove Red Dot sight from adapter

**Step 3:** Secure foundation of sight adapter to slide using T-15 screws in the DVT bag. Torque to **25 in/lb.**



**Step 4:** Secure top of sight adapter to base with supplied T-10 screws in the DVT bag. Torque to **25 in/lb.**







**Step 5:** Attach the optic to the Micro sight using the correct screws, torquing to **12 in/lb.**

Utilize liquid thread locker upon final installation of all threaded fasteners

**WARNING:** Failure to follow all installation guidelines including recommended torque specifications can lead to property damage and/or bodily harm

The **RED** circles indicate locations for 2 included alignment pins  
The **BLACK** circles indicate locations for mounting screws – Torque to 12in/lb

Sight Manufacturer	Sight Models	Screws Used
Swampfox	Sentinel	M3 x 8 
Springfield	Wasp	
J-Point	Micro	M3 x 6 
Crimson Trace	1500/1550	OEM Screws
Shield	RMSc/SMSc	M3 x 8 
Riton	3 Tactix MPRD 2.0 X3 Tactix V2	
Holosun	407/507K	M3 x 10 
Romeo	Zero	
	